




HOW FLOODING CAN OCCUR IN A HOME:: OVERLAND FLOODING, INFILTRATION FLOODING AND SEWER BACKUP




OVERLAND FLOODING




INFILTRATION FLOODING



SEWER BACKUP




BASEMENT FLOOD REDUCTION IN TYPICAL TWO-STOREY HOME




HOW MUCH WATER FLOWS FROM A ROOF




WINDOW WELLS AND COVERS



STORM SEWER LATERAL




BACKWATER VALVE OPERATIONS



Closed position


Prevents surcharge from backing up into building.




Open position

Allows normal operation of the sewer lateral.


BACKWATER VALVE




WEEPING TILE



SUMP PUMP INSTALLATION



PROPERTY LINE



DOWNSPOUT EXTENSION

